# **Upgrade Information of MPE720 Version 5.55**

## 1. Added and Improved Functions

Items added and features improved from MPE720 version 5.54 to version 5.55 are as follows.

No.	Feature	Classification
1	Display of alert message when servopack parameter is read.	Improvement
2	Improvement of check outside register range of IO message communication.	Improvement


### 2. Description

### No.1 Display of alert message when servopack parameter is read.

When the servo packing parameter screen is displayed, the alert message is displayed.

In the previous version, MPE720 automatically reads the servo packing parameter when the servo packing parameter screen is displayed. There was a possibility to influence when the axis was driven in the application because the command from the application was not accepted while reading it.

This alert message can avoid the influence of the application on operation because it can read the servo packing parameter after confirming driving the axis.



#### No.2 Improvement of check outside register range of IO message communication.

The register outside the range is not set on the setting of the communication of the IO message of 218IFA and 218IFC screen.

The register outside the range was set in the previous version.